


CONNECT RECORDER TO HIK-CONNECT


1

Right Click Menu




2

Type in Admin password and
Click Okay



3

Click Configuration




FOR INQUIRIES, CONTACT US ON
SERVICE@INSIDEOUTSECURITY.COM.AU
(07) 4243 6235

CONNECT RECORDER TO HIK-CONNECT


4

Click Network



5


Tick box beside Enable DHCP
and then click Apply



CONNECT RECORDER TO HIK-CONNECT

6

Click on Platform Access



7

Ensure Status is Online

