


# UNBINDING & RE-ADDING PHONE TO HIK-CONNECT


1

Click Scan QR Code



2

Scan QR Code on Platform Access section on Recorder




FOR INQUIRIES, CONTACT US ON  
[SERVICE@INSIDEOUTSECURITY.COM.AU](mailto:SERVICE@INSIDEOUTSECURITY.COM.AU)  
(07) 4243 6235

# UNBINDING & RE-ADDING PHONE TO HIK-CONNECT


3

Click Unbind Device



4

Connect to Wi-Fi



FOR INQUIRIES, CONTACT US ON  
[SERVICE@INSIDEOUTSECURITY.COM.AU](mailto:SERVICE@INSIDEOUTSECURITY.COM.AU)  
(07) 4243 6235

# UNBINDING & RE-ADDING PHONE TO HIK-CONNECT

5

Enter User Name and Password,  
enter Captha Code and Click Finish

Unbind Device

User Name: admin

The password here refers to the administrator password you created when you activate the device, rather than the device verification code.

5L6U

Finish

"5L6U"

q w e r t y u i o p

a s d f g h j k l

↑ z x c v b n m ↵

123 space return

😊 🎤

6

Follow 'Connect Phone to Hik-Connect'  
process, enter Captha Code and Click  
Finish

FOR INQUIRIES, CONTACT US ON  
[SERVICE@INSIDEOUTSECURITY.COM.AU](mailto:SERVICE@INSIDEOUTSECURITY.COM.AU)  
(07) 4243 6235

